


STEP 1:
COLLECT BOTH SIDE WELDMENTS.
LEFT HAND SIDE SHOWN ABOVE.

STEP 2:
AS SHOWN ABOVE SLIDE THE 1/4-20
x 5-1/2" BOLT WITH WASHER
THROUGH THE HOLE AND HAND
START THE WEDGE NUT ON THE
CHANNEL SIDE. REPEAT FOR ALL 4 -
ONLY HAND TIGHT.

STEP 3:
COLLECT THE LEFT SIDE WELDMENT
AND THE BACK PANEL WELDMENT.
WITH THE HORIZONTAL WIRES
FACING IN, SLIDE THE BACK PANEL
SQUARE TUBES OVER THE CHANNEL
SPUDS.

STEP 4:
REPEAT STEP 3 WITH THE RIGHT SIDE
WELDMENT. KEEP THE HORIZONTAL
WIRES ON THE SIDE TO THE RIGHT,
SAME AS THE LEFT SIDE.



STEP 5:
LINE UP THE TOP WITH THE PRE-
DRILLED HOLES TO THE HOLES ON
THE RIGHT AND LEFT SIDE. KEEP
RADIUS CORNERS TO THE FRONT.

STEP 6:
USE THE SUPPLIED SCREWS TO ATTACH
THE TOP AS SHOWN ABOVE.

STEP 7:
PLACE THE PLUG INTO POSITION

STEP 8:
TIGHTEN THE PLUG NUT ON THE
UNDERSIDE AS SHOWN ABOVE.
INSTALL SUPPLIED PLUGS AND SHELF.

GEARGRID		NAME	DATE	TITLE:
<small> PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF GEARGRID CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF GEARGRID CORPORATION IS PROHIBITED. INTERPRET DIM AND TOLERANCE PER ASME Y14.5M-1994 THIRD ANGLE PROJECTION </small>		<small> UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: ANGLE MACHINED ±.5" ANGLE FORMED ±1" TWO PLACE .XX ±.03 THREE PLACE .XXX ±.010 HOLE Ø ±.005 </small>	<small> ENGINEER DRAWN </small>	NIGHTSTAND ASSEMBLY
SIZE	PART NO.	REV		
D		01		
DO NOT SCALE DRAWING SHEET 1 OF 1				